Ruff ‘n Ready™
Bluetooth Speaker

Quick-Start Instructions

To play MicroSD sound card:

1. Charge speaker before first use
2. Hold ⏻ 2 seconds to turn on
3. Insert MicroSD (bronze side facing up), if not already pre-installed and press M for 1 second
4. Press − for 1 second to replay a track
5. Press and hold − to turn volume down
6. Press + for 1 second to skip track
7. Press and hold + to increase volume
8. Hold ⏻ for 2 seconds to turn off





60-Day Defective Merchandise Warranty

In the event of a defective iCalmPet product, purchased directly from iCalmPet.com, a replacement unit will be provided within 60-days of purchase.
https://icalmpet.com/customer-service/warranty/

30-Day Money Back Guarentee

If your speaker, CD, or MicroSD music program doesn’t meet your expectations, we will refund your purchase price. Due to technical transfers of downloads, returns are not possible. If there is dissatisfaction with any of our downloadable recordings, a partial iCalmPet credit will be issued.
https://icalmpet.com/customer-service/warranty/

iCalmPet™

Featuring the music of
Through a Dog’s Ear™ & Through a Cat’s Ear™

iCalmPet.com | CustomerSupport@iCalmPet.com | (541) 482-2134

©2007-2023 BioAcoustic Research, Inc. iCalmPet, Ruff ’n Ready, Through a Dog’s Ear, and Through a Cat’s Ear are registered trademarks. All rights reserved.